

Keybag & KeyCover sizing chart

KeyCover	Keybag	Example Keyboards
KC3 <i>878x253/287x40mm</i>		
KC4 <i>973x266/398x60mm</i>	KB44 <i>973x398x170mm</i>	Casio CTK3200, 3400, 3500, 6200, 7200 Yamal PSR E253, E263, E353, E363, E453 Yamal EZ220
	KB44s <i>936x330x100mm</i>	
	KB45 <i>1060x448x178mm</i>	
KC5 <i>1060x279/448x60mm</i>	KB45s <i>1060x356x132mm</i>	Yamal NP11, NP12
KC6 <i>1175x303/430x60mm</i>	KB46 <i>1175x430x200mm</i>	Casio WK-7600
	KB46S <i>1180x350x150mm</i>	
KC7 <i>1267x270/472x60mm</i>	KB47S <i>1267x350x116mm</i>	Yamal NP32 Yamal NPV80
	KB48 <i>1385x490x190mm</i>	Yamal DGX660 Yamal P115
KC8 <i>1385x338/470x60mm</i>	KB48s <i>1330x380x150mm</i>	Casio PX160, PX360 Korg SP170 Yamal P35, P45, P255 Yamal P105

Example keyboards are only a sample. Please measure your keyboard

Copyright Ackerman Music Ltd